

## Installation

Arrange on the fixing panel four threaded holes for screws or four 8,5 pass-by holes and follow the table.



Model	Α	В
P112 - P116	103	40
P124	194	46
P206 - P208	103	31
P306	103	31
P404	103	22
P505	103	31
P506 - P508	115	31
P5066 - P5068	115	31
P510	115	40
P606	*	
P608	50	30
P808	50	30
P1004	63	18

Fix the fixed part by M8 screws with eventual lock nut. For P124 use M12 screws or arrange pass-by holes diameter 13.



\*For P606 apply two brackets to the machine and install the fixed part by four screw.