

Istr. 218 mod. A0

LM 12 GAS
USE INSTRUCTION

easier to connect.

Faster


Istr. 218 mod. A0

LM 12 GAS
USE INSTRUCTION

easier to connect.

Faster


1 Disassemble.




2 Screw the coupling, the adaptor and the hose together with the bonded seals, respecting the torque indicated below.



3 Assemble the handle and fix it with screws (max torque 2 Nm).



4 Insert Faster coloured plastic tags to identify your lines. The tags are not included in the kit, but purchasable on request.



AVAILABLE TAGS

Symbol	Colour										
	Orange	White	Blue	Light Blue	Yellow	Grey	Brown	Black	Purple	Red	Green
+	ID A +	ID BI +	ID B +	ID C +	ID G +	ID GR +	ID M +	ID N +	ID P R4008 +	ID R +	ID V +
-	ID A -	ID BI -	ID B -	ID C -	ID G -	ID GR -	ID M -	ID N -	ID P R4008 -	ID R -	ID V -
1			ID B 1								ID V 1
2			ID B 2								ID V 2
3			ID B 3								ID V 3
4			ID B 4								ID V 4
5			ID B 5								ID V 5

The shade of colours in these instructions are for illustrative purposes only.